

# **TAXiTRONiC**

SmartTD







**USER MANUAL**

**INDEX**

1	CLOSED SHIFT .....	3
1.1	PARTIAL / CLOSURES .....	3
2	STATUS BAR.....	4
3	LOCATION.....	5
3.1	PENDING TRIPS .....	6
3.2	LOCATION QUERY .....	6
3.2.1	DETAILED ZONE INFORMATION .....	7
4	RECEPTION OF A TRIP.....	8
4.1	DISPATCH INFORMATION.....	9
5	PAYMENT MENU .....	10
5.1	AMOUNTS MENU.....	10
5.2	PAYMENT METHODS.....	10
5.3	SUBSCRIBER PAYMENT .....	11
5.4	CREDIT CARD PAYMENT .....	11
5.4.1	WITH CONNECTED BLUETOOTH PINPAD .....	11
5.5	WITH EXTERNAL POS .....	11
6	MESSAGES .....	12
7	<b>REQUEST VOICE</b> .....	13
8	INFORMATION / SERVICES.....	13
9	EMERGENCY POSITIONS .....	13
10	SENSORS VERIFICATION .....	14
11	PREFERENCES .....	15
12	TROUBLESHOOTING .....	17
13	HOMOLOGATED TERMINALS .....	18



# 1 CLOSED SHIFT

After starting the application, the available actions are:

	<p>Start with central. Starts a work session</p> <p>In the user ID screen, depending on the configuration, it may be necessary to enter a driver code, or an user and password.</p>
	<p>Close the application</p>
	<p>Open the Partial / Closures screen</p>
	<p>Open the application options as "Menu" button does.</p>
	<p>The smartphone "Menu" button <b>also</b> gives access to the application options.</p> <p>"Last applications" button must be pressed in some Smartphones. </p> <p>The "Menu" button picture may be different for each smartphone brand.</p>

## 1.1 PARTIAL / CLOSURES





The Partials / Closings screen displays the revenue Partials data. They may also be printed.

	<p>CLOSINGS: Prints the information of the revenues since the last cash closing, resets the values to zero and increases the closing number.</p>
	<p>PRINT: Prints the information of the revenues since last cash closing, allowing a basic management of incomes.</p> <p>The information is broken down into Cash, Credit and Subscriber.</p>


## 2 STATUS BAR



The line at the bottom displays the operating status of several systems connected to SmartTD.

	<p>Communication server connection status.</p> <ul style="list-style-type: none"> <li>• Green: Connection operative</li> <li>• Yellow : The server is available but the connection is not operative. Possibly the user is not active</li> <li>• Red: There is no connection to the server Possibly there is no 3G connection</li> </ul>
	<p>GPS Status</p> <ul style="list-style-type: none"> <li>• Green: connection with the GPS operative</li> <li>• Red: No GPS connection</li> </ul>
	<p>Status of the connection with the taximeter</p> <ul style="list-style-type: none"> <li>• Green: Connection with taximeter correct</li> <li>• Red: No connection with taximeter</li> </ul>
	<p>Taximeter status</p>

The upper line shows the status location and, if the taximeter is Hired, the current trip amount.








### 3 LOCATION

When the work session with central is started, the area in which the taxi is located is calculated, based on the GPS location. The information is automatically sent to the central.

If the position is within a work zone, the state changes FREE TO LOCATED IN AREA. When the taxi is located in zone, the location status is displayed in the status bar.

Location type	Zone name	Order in the zone
<ul style="list-style-type: none"> <li>• Stop</li> <li>• Area</li> <li>• Busy</li> </ul>	Shows the name of the zone where the taxi is located	The order in the zone is displayed for a configurable time

	<b>DISABLE LOCATION</b> When the driver does not want to receive trips from the central for a period
	<b>ACTIVATE LOCATION</b> When the location is disabled, and the driver wants to be available to receive trips again
	<b>LOCATED ON TAXI RANK</b> Available when the taxi is within the zone of influence of the Taxi Rank.
	<b>LOCATION QUERY</b> When the taxi is located, the location query is available.
	<b>PENDING TRIPS</b> When the taxi is located, gives access to the list of trips the central did not assign automatically, probably because there were no taxis in the appropriate zone.

If the option is enabled, it plays the location when it changes. It will stop playing if you exit the application, the status changes or the "Back" key in your smartphone is pressed. ↩

### 3.1 PENDING TRIPS



When the taxi is located, this gives access to the list of trips the central could not assign automatically, probably because there were no taxis in the appropriate zone.

Service 1	Zone pick up	Destination area	Street pick up	Requirements
Service 2	Zone pick up	Destination area	Street pick up	Requirements
Service N	Zone pick up	Destination area	Street pick up	Requirements

Upon receiving the trips list, clicking on one of them sends to the central the request for the assignment of the trip. If the central validates it, the taxi will receive the trip dispatch.

If the trip cannot be assigned, the taxi receives a message "TRIP NOT ASSIGNED"

If there are no available trips, the taxi receives a message "NO TRIPS".

### 3.2 LOCATION QUERY



The location query gives information about the distribution of work in the zones.

	Taxis in the Taxi Rank of the Zone	Taxis Located in the Zone	Taxis in Hired finishing a trip in the zone	Customers waiting for taxis
Zone 1..N	Green	Yellow	Red	White

Depending on the Radiotaxi settings, if this display is kept open, the information of the zone will be updated when the taxi moves, in this way the menu always displays the Taxi location

Once you use Scroll, the menu does not follow the Taxi location until you close the screen and open it again. This way, you can check the information of another zone, and the information does not change while reading.



The information of the Taxis on the zone is accumulated with the taxis on Rank, because they have more priority than the taxis in the Zone.

The same is applied to Taxis in Hired: This information is accumulated with the taxis in the Rank and in the Zone

This allows to know easily, without having to calculate mentally, the priority in the zone you will have when you locate into a zone, in any of the three location types.

The field "Customers waiting for taxis" may include future trips for the next N minutes, depending on the Radiotaxi configuration.

The actions on this screen are:

	Scroll
	Back to the previous level, and closing the location query is done with the smartphone Back button.

Macrozones are work areas which contain several Zones. The info on the Macrozones contains all the zones inside of it.

### 3.2.1 DETAILED ZONE INFORMATION



It provides detailed information of the taxis in the zone

Zone name	Taxis in the Rank	Taxis in the Zone	Taxi ending the trip
Order number	Taxis located in the Zone, With location time	Taxis located In the zone	Taxi ending the trip in the Zone



Trip details in the Zone gives information about the available trips in the zone

Zone name	Trips in the Zone	Requirements
Order in the zone	Pick up time	Trip requirements

These functions can be enabled or disabled depending on the Radiotaxi settings

## 4 RECEPTION OF A TRIP

When the taxi receives a Trip, the following information is displayed:

Pickup time	Pick up Zone	Trip Requirement
	You have a new trip	Pick up address
	Do you accept it?	

Part of this information is optional, depending on the Radio Taxi settings.

There is a maximum time to accept a trip. If it is not accepted in time, it will be automatically refused.

After accepting the trip, the available options are:

	<p><b>TRIP INFORMATION</b></p> <p>Once the trip has been accepted, the complete information of the trip is displayed. When in the "Trips" screen, this button can be used to display the information again.</p>
	<p><b>AT THE DOOR</b></p> <p>If the customer has requested to receive a notification when the taxi arrives, the AT THE DOOR button is enabled. When selected, the customer will receive the notification</p>
	<p><b>NO CUSTOMER</b></p> <p>When you reach the pick up address and the customer is not present, select NO CUSTOMER. The Central will manage the notification and will give instructions</p>
	<p><b>CUSTOMER IN</b></p> <p>If the customer arrives after the driver had already used NO CUSTOMER, notify the central with CUSTOMER IN. This way the central will not waste time looking for the customer, who is already in the taxi.</p>
	<p><b>RETURN TRIP</b></p> <p>Use it if you have accepted a trip but it is necessary to return it to central.</p> <p>In some Radiotaxis, returning trips may be a reason for a penalty, therefore inform yourself on the policy of your fleet before using this function.</p>
	<p><b>DISABLE ROOFLIGHT</b></p> <p>When the taxi has a dispatch, you may disable the FREE light. This avoids confusion for the rest of customers on the street, who see a FREE taxi which is really not available for them</p> <p>This function may be disabled if the local regulations don't allow it.</p>



## 4.1 DISPATCH INFORMATION

Once the trip has been accepted, the complete information of the trip is displayed. When in the "Trips" screen, this button can be used to display the information again.



DESPACHO  
032357 - 18:08 - BAC DE RODA

NOMBRE  
AAAAAA

RECOGIDA  
PERU(DEL), C 104 ,BARCELONA

OBSERVACIONES  
\*\*\*CONTADO\*\*\*

SMART  
TD

TAXITRONIC

IMPRIME DESPACHO    NAVEGADOR GPS    DESTINO

	<p>Navigate to the pickup address. The address is sent to any navigator installed in the Smartphone, by default Google Maps.</p>
	<p>DESTINATION</p> <p>If the customer has communicated the trip destination, use this button to see the destination details or to navigate to the destination.</p>

If the option is enabled, it plays the dispatch information when it is received or consulted. It will stop playing if you exit the application, the status changes or the "Back" key in your smartphone is pressed. ↩

## 5 PAYMENT MENU

There is a Payment menu to be able to pay the trip with different methods. When the terminal is in Payment mode, it is possible that the taximeter may not pass to Free until the payment is done.

### 5.1 AMOUNTS MENU

The amounts menu lists the amount concepts and the total amount. The amount concepts are:

Taximeter amount	Always. Non editable
Extras amount	If entered in the Taximeter.
Tips	Optional
Tolls	Optional
Total	Total amount




Tips and Tolls are configurable depending on local regulations. Tolls are used if the taxi has gone through a Toll (highway, Tunnel) and the Tolls are to be paid by the passenger.



If while in the Amounts menu you press the “Back” button, it will return to Dispatched and you will be able to restart the trip without losing the dispatch. This function is configurable and may be activated or deactivated by your Radiotaxi.

### 5.2 PAYMENT METHODS


After the Amounts menu, next screen is the Payment methods. Depending on the configuration, the following methods may be available:

	Cash payment
	Subscriber payment
	Credit card payment

The menu closes automatically after a default time of 60 seconds, after which a payment method is chosen automatically.

## 5.3 SUBSCRIBER PAYMENT


If the trip was sent as Subscriber from the Central, the payment is started by default as Subscriber. The onscreen menus may vary depending on the trip or the subscriber properties.

	<p>Depending on the Subscriber properties, you may have to enter an Authorization code.</p> <p>If the payment is authorized, the Subscriber Payment tickets are printed.</p> <p>If the Subscriber payment is rejected, it is possible to select a different payment method</p>
---	--

## 5.4 CREDIT CARD PAYMENT


### 5.4.1 WITH CONNECTED BLUETOOTH PINPAD

If SmartTD is connected to a Bluetooth PinPad device for credit card payment, the functionality of this button is:




	<p>When selecting “Credit Card Payment” the amounts are sent to the Bluetooth PinPad. The credit card payment is done in the PinPad.</p> <p>SmartTD receives the notification of payment Accepted / Rejected</p> <ul style="list-style-type: none"> <li>• In case it has been accepted, it will print the payment tickets and then go to Free.</li> <li>• In case it has been denied, it returns to the Payment menu so you can try with a different card or to pay Cash.</li> </ul> <p>Payments done with credit card are counted in the Closing report under the Credit Card title.</p>
---	---


Note: This functionality is currently under certification test in some countries. Please check with your distributor to find out about availability in your country and which banks are available.

## 5.5 WITH EXTERNAL POS

	<p>In case there isn't any connected Bluetooth PinPad, the “Credit Card Payment” button is used to count the payment done in the external POS device in the Closings report under the Credit Card title.</p> <p>This helps in your income accounting, even if the payment was not done from SmartTD itself.</p>
---	---

## 6 MESSAGES

	List of received messages
	Print a message
	<p>Erase a message from the list. It is possible to erase one or several stored messages. A button allows toggling the selection and select all messages.</p> <p>Select the messages you want to erase, and then Erase.</p>



If the option is enabled, it plays the message when it is received or consulted. It will stop playing if you exit the application, the status changes or the "Back" key in your smartphone is pressed.





## 7 REQUEST VOICE



Click here to request voice communication with the operator. The operator will contact the driver when available.

## 8 INFORMATION / SERVICES

	<p>Information</p> <p>Opens a configurable menu with the different options the taxi can query the Radiotaxi central about. After selecting the desired option, the central answers with the requested information.</p>
	<p>Services</p> <p>Opens a configurable menu with the different service requests from the taxi to the central. After selecting the desired option, the central will manage the request.</p>

## 9 EMERGENCY POSITIONS

If there is an emergency button connected to the taximeter, pressing the button for more than 3 seconds starts sending emergency positions to the Radiotaxi.

For the first seconds the emergency triangle is displayed in Orange. When the central confirms the emergency has been received, the triangle changes to Green



The emergency is always finalized by the Radiotaxi. When the triangle icon disappears, it means that the Central has checked the Emergency situation, has taken the adequate measures, and has finalized the Emergency status.

If the triangle is displayed in Red, there is a breakdown in the emergency button or in its cabling.

## 10 SENSORS VERIFICATION

There is a method to check the correct functioning of the Contact Key and the Alarm Button connected to the taximeter.

Open a shift so that SmartTD connects to the taximeter. Go back to Closed Shift, and enter the GPS menu. You will see a key icon for the Contact Key, and an emergency triangle for the Emergency Button.

In this state, you can press the Emergency button to check it and the emergency will not be sent to the central. This permits a verification of the correct functioning of the button.




The meaning of each color is:



	Contact Key Status	Emergency Button Status
Green	ON	Pressed
Red	OFF	Not pressed
Grey	Not detected	Not detected

## 11 PREFERENCES

In closed shift you can access the “Preferences” menu, in which it is possible to configure a few optional functionalities.



Roof Light Off in Dispatched	Let you choose if the roof light turns off automatically, without pressing the button, when a trip is received
Beep if located + Disconnected from TX	Plays an audio notification when SmartTD has become disconnected from the taximeter over Bluetooth if it was located, to warn that the location may be lost after a timeout
Vibrate + Sound	Adds vibration to the audio notifications
TTS (Text To Speech) for messages	Enables message location
TTS for dispatches	Enables dispatches location

TTS for location	Enables location location
GPS Navigator App	<p>Lets you choose the App to execute the navigation. Available options are Google Maps or a generic application chosen by the user. If your central is Alfa6, the supported GPS navigators are: Waze, Route66 y Yandex.</p> 
Keep Screens ON	<p>Lets you choose if the screen is turned off or reduce its brightness after a time without interacting with it</p> 
Service Ringtone	Use Service Ringtone to choose a system sound or personalized tone for an incoming dispatch
Notification Sound	Lets you choose a system sound or personalized tone for a notification, for instance a message from central
Pin-Pad Serial Number	Lets you configure the serial number of a connected Bluetooth Pin-Pad of certain payment provider




## 12 TROUBLESHOOTING

Problems have been detected in the Bluetooth connection when the user has activated the power saving options in the Android

The configuration of this option has to be:

Power saving:

**Deactivated.**




Problems have been detected when the user had changed certain developer options in the Android. The configuration of these options must be:

Do not keep activities:

**Deactivated**

Limit background processes:

**Standard limit**



## 13 HOMOLOGATED TERMINALS

The homologated terminals are:

### Smartphones

bq	Aquaris E5 4G	Aquaris E5
Huawei	Ascend G7	G7-L01
	Huawei P8 Lite	ALE-L21
	Huawei P8	GRA-L09
LG	G4	LG-H815
	G4c	LG-H525n
Motorola	Motorola MotoG 4G	XT – 1039
	Motorola MotoG (3ª generación)	XT – 1541
	Motorola Nexus 6	XT – 1100
Orange	Nura	Alcatel One Touch M812
Samsung	Galaxy A5	SM – A500FU
	Galaxy A3	SM – A300FU
	Galaxy S6	SM – G920F
	Galaxy S5	SM – G900F
	Galaxy S4	GT – I9505
	Galaxy S4 mini	GT – I9195
	Galaxy Note4	SM-N910F
	Galaxy Note3	GT – N9005
	Galaxy Express2	SM – G3815
	Galaxy Grand Neo	GT-I9060
	Galaxy Grand Prime	SM-G531F

Sony	Xperia Z3	D6603
	Xperia Z3 Compact	D5803
	Xperia ZUltra	C6833
Wiko	Rainbow 4G	Rainbow 4G

## Tablets

Asus	Fonepad 7	K00Z
Samsung	GalaxyTab4 7.0 4G	SM – T235
	GalaxyTab3 7.0 3G	SM – T211

## Previous terminals:

## Smartphones

Lenovo	A880	A880
LG	Optimus L7	P700
	Nexus 4	E960
Samsung	Galaxy S3	GT – I9300
	Galaxy S3 mini	GT – I8190
	Galaxy S2	GT – I9100
	Galaxy Note2	GT – N7100
Sony	Xperia T2 Ultra	D5303
	Xperia Z1	C6903
	Xperia Z	C6603

## Tablets

Samsung	GalaxyTab2 7.0 3G	GT – P3100
---------	-------------------	------------